



VISUAL
PHYSICS

SHORT NOTES

CHAPTER Conductors



+91 999021287





www.visualphysics.in



GET IT ON
Google Play


CONDUCTORS




★ Field inside the conductor in electrostatic must be zero.

Induce charge will always be on the surface
 so that $q_{\text{net inside}} = 0$, hence $\vec{E}_{\text{net}} = 0$


as $\boxed{|\vec{E}_{\text{net}}| = \frac{q_{\text{net}}}{A \epsilon_0}}$



charge will distribute such that, $\vec{E}_{\text{net}} = 0$
 inside the conductor. And that distribution
 may or may not be Uniform.




Hence, $\vec{E} = 0$ inside cavity of conductor




* Field inside an empty cavity = 0.

So inside a metal cage, in case of lightning as car.




if there is cavity?



- ★ (i) cannot be field inside the cavity
- (ii) Net charge inside the cavity

from the excess charge given over the conductor

If a charged conductor placed inside the field:



Charge Inside the Cavity

distribute such that $E=0$

Induced charge

charge distribution independent of inside charge cavity

Gaussian surface
 $\phi=0$ as $E=0$
 $\Rightarrow q_{net}=0$

charge will come over the surface of conductor, due to induce charge over the cavity

means, equal & opposite charge must induce over surface.



Now,

Inside charge distribution effected only by charge inside cavity


External field can only change charged distribution over surface

* Inside charge distribution is unaffected by external field presence

System of cavity and charge is unaffected by external field.



Potential of Conductor:




potential at every point inside a conductor is same, even inside empty cavity.


between a & b, no potential difference.

$V \neq 0 \rightarrow V = \text{constant}$
 potential is not zero,
potential difference is zero

if charge inside cavity?




$V_a \neq V_b \Rightarrow V_a - V_b \neq 0$
 as $E \neq 0$ inside cavity
 but, throughout the body of conductor potential is same.



Earthing :


As potential inside the conductor = potential on the conductor



so now potential of both the conductors must be same.

Hence must be charge transfer.

so, $Q_1 \rightarrow q_1$ $Q_2 \rightarrow q_2$




if $R_2 \rightarrow \infty$ $\Rightarrow$ $\left(\frac{k q_2}{R_2} \right)$ become zero

so that means, $\frac{k q_1}{R_1} \rightarrow 0$
 only possible when $q_1 \rightarrow 0$


same case with when we connect with earth
 $R_2 \rightarrow \infty$, $V \rightarrow 0$, but $q \rightarrow$ high for earth

but $V = \frac{k q}{R_2} \rightarrow 0$ (Not exactly zero)

so, When we connect a conductor to earth
 $V \rightarrow 0, \Rightarrow q_1 \rightarrow 0$, all charge of conductor flows into earth.



so, for the case




$\vec{E}$ -field outside the conductor:

At surface of conductor

$\vec{E} \perp$ to surface, so no component along surface.

As if $\vec{E}$ is along surface charge starts to move




if $\vec{E}_{ext} = 0$, $\vec{E}_{net}$ = due to charge on surface.


★ Net field is always perpendicular to conductor surface at every point
But, not necessarily, charge density is equal.

★ charge distribution, depends on condition

In general, σ is more near more curvy region as compared with less curvy one.



Why?



$$\frac{k q_1}{R_1} = V = \frac{k q_2}{R_2}$$

$$\Rightarrow q_1 = \frac{q_2 R_1}{R_2}$$

$$\sigma_1 = \frac{q_1}{4\pi R_1^2} \quad \& \quad \sigma_2 = \frac{q_2}{4\pi R_2^2} \Rightarrow \sigma_2 < \sigma_1$$

$$\Rightarrow \sigma \propto \frac{1}{R}$$

from this
if R is less σ is high

means R is less $\rightarrow$ more curvy nature.
more σ $\rightarrow$ charge density.

Now, for plane surface, $r \rightarrow \infty$

$\sigma \rightarrow 0$ This is not the case.

as we know for plane sheet charge is also over the surface not only in corners.

$\sigma \propto \frac{1}{R}$
is just relation
between two curvy
regions

$\gamma \rightarrow \infty$ not possible.

charge density is high

but, charge is also on plane surface

Now,

$$\sigma_A > \sigma_C > \sigma_E > \sigma_D$$



(5) & (4)
negative curviness
↳ bulging inwards.

(1, 2, 3) → positive curviness
↳ bulging outwards


★ σ is high at more curvy regions holds only for bulging outwards surface.

★ σ is less at more curvy regions for bulging inwards surfaces.

This holds till $\vec{E}_{\text{ext}} = 0$

so this relation only valid for isolated charged conductors.

Now for a case,



So, gauss law $\rightarrow$
$$\frac{Q_{net}}{\epsilon_0} = E A$$
 Area of part considered

$Q_{net} = \sigma A$



So,
$$E = \frac{\sigma}{\epsilon_0}$$

high for high curvy
So E will be high and vice-versa

So, E is different at different points,
as σ is different for different points.

Conducting Sheets:

charge distribute such that $\vec{E}=0$ inside



Now here we have four sheets

①		②		③		④
$Q_1 - q_1$	$E=0$	q_1		q_2		$Q_2 - q_2$
	A •			B •		$E_4 = -\frac{(Q_2 - q_2)}{2A\epsilon_0}$
$E_1 = \frac{(Q_1 - q_1)}{A2\epsilon_0}$		$E_2 = \left(\frac{-q_1}{A2\epsilon_0} \right)$		$E_3 = -\frac{q_2/A}{2\epsilon_0}$		

E_1, E_2, E_3, E_4 are field by ①, ②, ③ & ④ at point A

now, $E_1 + E_2 + E_3 + E_4 = E_A = E = 0$

on solving we get


$$q_1 = \frac{Q_1 - Q_2}{2}$$

Similarly, if we solve for point ③


we get, $q_2 = -\frac{(Q_1 - Q_2)}{2}$

★ So we can have net charge on each surface from, q_1 & q_2 .

on solving.



so In general.




*

So, from charge conservation and using the condition for the charge outside the surface of system we can have charge on each plate.

Electrostatic pressure.

as, $\boxed{\vec{F} = q \vec{E}_2}$ field due to rest of charge
charge free

- (i) $\vec{E}$ field in space is continuous.
 (ii) Field distribution is discontinuous at a surface charge density, distribution



now $E_{net} = E_{other} + E_{patch} = E_{above}$

$E_{net} = E_{other} - E_{patch} \Rightarrow E_{below}$
 field due to the surface except the considered patch

so, $E_{above} + E_{below} = 2E_{other}$
 $\Rightarrow \boxed{E_{other} = \frac{E_{above} + E_{below}}{2}}$

So, field at patch = $\frac{1}{2} (E_{\text{above}} + E_{\text{below}})$

if patch Area $\rightarrow dA$

$\hookrightarrow \sigma$

$$\text{So, } dq = \sigma dA$$

$$\Rightarrow dF = dq E_{\text{other}}$$

$$\Rightarrow \left(\frac{dF}{dA} \right) = \sigma \left[\frac{1}{2} (E_{\text{above}} + E_{\text{below}}) \right]$$

$P =$ electrostatic pressure

for conductor,

$$E_{\text{below}} = 0$$

$$E_{\text{above}} = \frac{\sigma}{\epsilon_0}$$

$$\text{So, } P = \frac{\sigma^2}{2\epsilon_0}$$

$\rightarrow$ Electrostatic pressure on the surface of conductor